




COBRA SYSTEM PISTOL CROSSBOW



WARNING

| Keep all body parts clear of the bowstring and cable paths during use. Always keep hand , thumb and fingers below flights track. Failure to do so may cause serious injury. Read and understand the manual before shooting. **DO NOT DRY FIRE** Shooting without an arrow or without any proper arrow will damage this crossbow and could lead to serious injury.





1

ASSEMBLY

Insert prod into stock to the white line. Make sure the pressure pad is in place between the prod and the prod retaining screw. Do not over tighten.



2

Feed the prod cover tight to the both side of the prod. Feed the string loop over the left end of the prod. Hold the right end of the prod in your right hand and the string with your left hand. With a friend's help to bend the right end of the prod and slips the string loop over it. Make sure the string fits snugly into the slots on the prod.



3

COCKING

1. While holding the crossbow with the left hand, pull the cocking mechanism down to cock the crossbow. The safety latch will automatically engage.
2. Return cocking mechanism to original position. The crossbow is now ready to accept the bolt.



4

LOADING

Place the bolt on the track as shown. Make sure that the bolt is fully back against the trigger mechanism.



5

Release the safety mechanism. The crossbow is now ready to shoot.



6

SIGHT ADJUSTMENTS

Adjust the sight mechanism right or left by turning the adjustment screw clockwise(left) or counter-clockwise(right). Adjust elevation screw clockwise for high shots, counter-clockwise for low shots.